



Using FON-375 Telephones with FortiVoice Enterprise Systems



The reference card includes the basic features.
For more information, see the phone's user guide.

Buttons

Most of the buttons are similar to those on other phones, but you might not be familiar with the following:


-  — Puts a call on hold
-  — Transfers a call

Softkeys — The screen shows the current function of each of the 4 softkeys. Softkeys change based on the call status.


Remember

Press **#** after dialing an outside number or extension.

Setting up voicemail

1. Press .
2. When prompted, enter a password, record a greeting and record your name for the dial-by-name directory.

Checking voicemail

1. Press .
2. When prompted, enter your password + **#**.
3. Press **1** to listen to your messages. You can also change your greeting and personal options.

Calling an outside number

1. Dial the phone number + **#**.
2. If prompted, dial an access code.

Calling an extension

Dial the extension number + **#**.

Placing a caller on hold

Press *Hold*. You can now hang up or answer another call without disconnecting the caller.

Retrieving a caller on hold

Press *Hold*.

Performing a screened transfer

A screened transfer allows the recipient to accept or refuse the transfer.

1. Press *Hold* + <extension> (or outside number) + **#**.
2. When the recipient answers:
 - press *Hold* or hang up to complete the transfer or
 - press *OK* and scroll to select *Cancel Transfer*.

Performing a blind transfer

Press *Hold* + <extension> (or outside number) + **#**, then hang up.

Voicemail

Access mailbox:

Locally

Remotely

* 9 8 #



Go to old messages

2

Change personal options

0

(greetings, password, remote notification options)

MESSAGE PLAYBACK CONTROLS

Go to first message

1

Restart

2

Go to end

3

Play previous message

4

Play next message

6

Delete message

7

Forward message

8

Save message

9

Exit

#

FORTINET®

Using FON-375 Phones with FortiVoice Enterprise Systems

Accessing Features

Do not disturb

* 7 8 # to enable

* 7 9 # to disable

Pick up: Any ringing extension

* 8 0 + #

Pick up: Specific extension

* 8 1 + <extension> + #

Place caller on hold

Hold

Retrieve caller on hold

Hold



Accessing Features

Answer call waiting

Press *OK*.

Screened transfer

Hold + <extension> (or outside number) + **#**, then *Hold* or hang up.
To cancel the transfer, press *OK* and scroll to select *Cancel Transfer*.

Blind transfer

Hold + <extension> (or outside number) + **#**, then hang up.

Voicemail transfer

Hold + *** 9 2** + <extension> + **#**, then hang up.

Conference call

Hold + <extension> (or outside number) + **#**.
Press *OK* and scroll to select *Conference*.

Park a caller









Hold + *** 4** + **#**.
The system will respond with a parking orbit.

Two-way intercom paging to FortiFone telephones

Press the programmed *Intercom* + <extension> + *Dial*,
or *** 9 2** + <extension> + **#**.

Two-way group paging to FortiFone telephones

Dial the <paging group number> + **#**.

Button	Function
	Hold — places and retrieves calls on hold.
	<i>Transfer</i> — transfers calls to another extension or outside line.
	<i>Conference</i> — brings multiple calls together in a conference.
	Voicemail — accesses voicemail and voicemail greetings. Password is 123123
	<i>Redial</i> — places a call to the last number dialed.
	<i>Mute</i> — toggles the microphone on and off.
	Headset — toggles the headset on and off.
	<i>Speakerphone</i> — toggles the speaker on and off.

- To CHANGE VOICEMAIL PASSWORD:
 - Press MAIL button
 - **GENERIC PASSWORD IS 123123**
 - Press the number ZERO
 - Press the number FIVE
 - Enter your new code (4 to 6 numbers) and the # key.